




SYSTEM




## SINGLE 18 FRAME

LINE

PORTO GM, PROSPER GM








## COMPONENTS








**You must remember to purchase self-tapping screws to construct each door (4 screws per door). When using safety glass, you must also remember to purchase gaskets 18.**

## DEPENDENT ON FLOOR TYPE, YOU MAY CHOOSE FROM DIFFERENT BOTTOM TRACKS






		Handle length = door height			
		LINE PORTO GM		LINE PROSPER GM	
		Handle Porto GM	Guiding carriage Gemini	Handle Prosper GM	Guiding carriage Gemini
					
Track <b>HIDE N</b> door height	- h	$h = H - 40 \text{ mm}$		$h = H - 40 \text{ mm}$	
door wing height with soft-close fitted Track <b>HIDE N</b>		Mini SV25/40/60 SV-25/50	$h = H - 40 \text{ mm}$	Mini SV25/40/60 SV-25/50	$h = H - 40 \text{ mm}$
		Top SV60/80, Central SV25/40	$h = H - 44 \text{ mm}$	Top SV60/80, Central SV25/40	$h = H - 44 \text{ mm}$
Track <b>HIDE W</b> door height	- h	$h = H - 42 \text{ mm}$		$h = H - 42 \text{ mm}$	
door wing height with soft-close fitted Track <b>HIDE W</b>		Mini SV25/40/60 SV-25/50	$h = H - 42 \text{ mm}$	Mini SV25/40/60 SV-25/50	$h = H - 42 \text{ mm}$
		Top SV60/80, Central SV25/40	$h = H - 46 \text{ mm}$	Top SV60/80, Central SV25/40	$h = H - 46 \text{ mm}$
Track <b>HIDE: M, G, track seat HIDE M</b> door height	- h	$h = H - 35 \text{ mm}$		$h = H - 35 \text{ mm}$	
door wing height with soft-close fitted <b>HIDE M, HIDE G, track seat</b>		Mini SV25/40/60 SV-25/50	$h = H - 35 \text{ mm}$	Mini SV25/40/60 SV-25/50	$h = H - 35 \text{ mm}$
		Top SV60/80, Central SV25/40	$h = H - 39 \text{ mm}$	Top SV60/80, Central SV25/40	$h = H - 39 \text{ mm}$
board height	- hb	$hb = h - 64 \text{ mm}$		$hb = h - 64 \text{ mm}$	
assumed door width	- w	$w$		$w$	
board width	- wb	$wb = d - 41 \text{ mm}$		$wb = d - 31 \text{ mm}$	
lower horizontal profile length - L		$L = U = w - 58 \text{ mm}$		$L = U = w - 48 \text{ mm}$	
upper horizontal profile length - U					
mirror height	- hm	$hm = hb$		$hm = hb$	
mirror width	- wm	$wm = wb - 4 \text{ mm}$		$wm = wb - 4 \text{ mm}$	




## ATTENTION!

Mirror (4 mm) should be used with a safety backing film. Safety glass (4.5 mm) comprises of two thin layers with a film in-between. Both mirror and glass need fitting gaskets U18.



### Installation method for fitting 18 mm board (diag. A) and 4 mm mirror or glass (diag. B)

- with handle      - with upper profile      - with lower profile



construction clearance included in the calculation of the height of board