


COMPONENTS

Handle Comfort II L: 2.70 m textile door stop (inserted) 4.8 mm x 4 mm anti-dust brush (self-adhesive) 6.7 mm x 13 mm #16, #18	Top track Comfort-Decor L: 1.70 m, 2.35 m, 3.00 m, 4.05 m, 6.00 m 94 mm	Bottom track Comfort L: 1.70 m, 2.35 m, 3.00 m, 4.05 m, 6.00 m 62 mm
Guiding carriage Comfort 	Angle section ZW L: 1.70 m, 2.35 m, 3.00 m 20 mm x 18 mm	Bottom carriage WD 18C HI-TEC

Dimensions of opening




Handle length = door height

door height	- h	$h = H - 42 \text{ mm}$
door wing height with soft-close fitted	Mini SV25/40/60, SV-25/50	$h = H - 42 \text{ mm}$
	Top SV60/80, Central SV25/40	$h = H - 44 \text{ mm}$
board height	- hb	$hb = h - 2 \text{ mm}$
door width	- w	$w = (W - 3 \text{ mm} + Z) : N$
board width #18	- wb	$wb = w - 7 \text{ mm}$
board width #12	- wb _m	$wb_m = w - 7 \text{ mm}$
angle section length	- la	this size is determined after door construction

number of doors	- N	2	3	4	5
total overlap	- Z	35 mm	70 mm	105 mm	140 mm

visual design – 4 wings

	$w = (W - 3 + 105) : 4$
	$w = (W : 2 + 32) : 2$




mirror dimensions

mirror height	- hm = hb - 4 mm
mirror width	- wm = wb _m - 34 mm


ATTENTION:
board to mirror contact area should be free from dirt and grase before applying double-sided tape

Broken line indicates recommended positioning of double-sided tape




- When fitting handle profiles, do not use assembly adhesive
- The handle should be fixed to board with fastening screws on the inner door face



Installation method for handle and guiding carriage with # 18 mm board (handle Comfort # 18 mm)



Installation method for handle and guiding carriage with # 12 mm board + # 4 mm mirror (handle Comfort # 16 mm)



Installation method for angle section 20 mm x 18 mm



ATTENTION!


Angle section must be fastened to board with minimum 3 screws Ø 3 x 25.

ATTENTION!

Handle profile should be 2 mm longer than board height.

WARNING

SEVROLL does not bear any responsibility for deformation resulting from the application of improper quality of boards (improper storage, improper humidity)




COMPONENTS

Handle MiniComfort II L: 2.70 m textile door stop (inserted) 4.8 mm x 4 mm # 18 mm	Top track Comfort-Decor L: 1.70 m, 2.35 m, 3.00 m, 4.05 m, 6.00 m 94 mm	Bottom track Comfort L: 1.70 m, 2.35 m, 3.00 m, 4.05 m, 6.00 m 62 mm
Guiding carriage Comfort 	Angle section Mini L: 1.70 m, 2.35 m, 3.00 m 11 mm x 17 mm	Bottom carriage WD18C HI-TEC



Dimensions of opening




Handle length = door height

door height	- h	$h = H - 42 \text{ mm}$	
door wing height with soft-close fitted	Mini SV25/40/60, SV-25/50	$h = H - 42 \text{ mm}$	
	Top SV60/80, Central SV25/40	$h = H - 44 \text{ mm}$	
board height	- hb	$hb = h - 2 \text{ mm}$	
door width	- w	$w = (W - 3 \text{ mm} + Z) : N$	
board width #18	- wb	$wb = w - 7 \text{ mm}$	
angle section length	- la	this size is determined after door construction	

number of doors	- N	2	3	4	5
total overlap	- Z	20 mm	40 mm	60 mm	80 mm

visual design – 4 wings	
	$w = (W - 3 + 60) : 4$
	$w = (W : 2 + 17) : 2$




ATTENTION!



Handle profile should be 2 mm longer than board height.

- When fitting handle profiles, do not use assembly adhesive

Installation method for handle and guiding carriage with # 18 mm board (handle Comfort # 18 mm)




Installation method for angle section Mini 11 mm x 17 mm




WARNING


SEVROLL does not bear any responsibility for deformation resulting from the application of improper quality of boards (improper storage, improper humidity)




COMPONENTS




With **Unicomfort** set you may use bottom track ***Doubler II with covering strip*** along with bottom carriage WD18V HI-TEC. **Fitting measurements are not affected.**



Stopper
HI-TEC



Dimensions of opening




Handle length = door height

door height	- h	$h = H - 42 \text{ mm}$	
door wing height with soft-close fitted	Mini SV25/40/60, SV-25/50	$h = H - 42 \text{ mm}$	
	Top SV60/80, Central SV25/40	$h = H - 44 \text{ mm}$	
board height	- hb	$hb = h - 2 \text{ mm}$	
door width	- w	$w = (W - 3 \text{ mm} + Z) : N$	
board width #18	- wb	$wb = w - 40 \text{ mm}$	
board width #12	- wb _m	$wb_m = w - 7 \text{ mm}$	
angle section length	- la	this size is determined after door construction	

number of doors - N	2	3	4	5
total overlap - Z	35 mm	70 mm	105 mm	140 mm

visual design – 4 wings

	$w = (W - 3 + 105) : 4$
	$w = (W : 2 + 32) : 2$




mirror dimensions

mirror height	- hm = hb - 4 mm
mirror width	- wm = wb _m - 36 mm


ATTENTION:
board to mirror contact area should be free from dirt and grase before applying double-sided tape

Broken line indicates recommended positioning of double-sided tape




- When fitting handle profiles, do not use assembly adhesive
- The handle should be fixed to board with fastening screws on the inner door face


Installation method for handle and guiding carriage with # 18 mm board



Installation method for handle and guiding carriage with # 12 mm board + # 4 mm mirror



Installation method for angle section ZW (20 mm x 18 mm)



ATTENTION!

Angle section must be fastened to board with minimum 3 screws Ø 3x25.

ATTENTION!

Handle profile should be 2 mm longer than board height.

WARNING

SEVROLL does not bear any responsibility for deformation resulting from the application of improper quality of boards (improper storage, improper humidity)