









## COMPONENTS




Stopper HI-TEC





Dimensions of opening




Handle length = door height

ALFA II C		VICTORIA II C		FAWORYT II C	
 #16 / #18		 #16 / #18		 #16 / #18	
h = H - 42 mm		h = H - 42 mm		h = H - 42 mm	
Mini SV25/40/60 SV-25/50	h = H - 42 mm	Mini SV25/40/60 SV-25/50	h = H - 42 mm	Mini SV25/40/60 SV-25/50	h = H - 42 mm
Top SV60/80, Central SV25/40	h = H - 44 mm	Top SV60/80, Central SV25/40	h = H - 44 mm	Top SV60/80, Central SV25/40	h = H - 44 mm
hb = h - 2 mm		hb = h - 2 mm		hb = h - 2 mm	
w = (W - 3 mm + Z) : N		w = (W - 3 mm + Z) : N		w = (W - 3 mm + Z) : N	
wb = w - 22 mm		wb = w - 19 mm		wb = w - 19 mm	
wb <sub>m</sub> = w - 7 mm		wb <sub>m</sub> = w - 7 mm		wb <sub>m</sub> = w - 7 mm	
la = dw - 48.4 mm		la = w - 33.6 mm		la = w - 33.6 mm	
hm = hb - 4 mm		hm = hb - 4 mm		hm = hb - 4 mm	
wm = wb <sub>m</sub> - 20 mm		wm = wb <sub>m</sub> - 16 mm		wm = wb <sub>m</sub> - 16 mm	

number of doors - N	2	3	4	5	2	3	4	5
total overlap - Z	36 mm	72 mm	108 mm	144 mm	18 mm	36 mm	54 mm	72 mm

visual design – 4 wings			
	$w = (W - 3 + 108) : 4$		$w = (W - 3 + 54) : 4$
	$w = (W : 2 + 33) : 2$		$w = (W : 2 + 15) : 2$




## ATTENTION!

Handle profile should be 2 mm longer than board height.

## WARNING


SEVROLL does not bear any responsibility for deformation resulting from the application of improper quality of boards (improper storage, improper humidity)

ALFA II C  
VICTORIA II C  
mirror dimensions



**ATTENTION:**  
Board to mirror contact area should be free from dirt and grease before applying double-sided tape.

FAWORYT II C  
mirror dimensions




Broken line indicates recommended positioning of double-sided tape






## VICTORIA II C, ALFA II C

## Installation method for handle and guiding carriage with # 18 mm board



- When fitting handle profiles, do not use assembly adhesive
- The handle should be fixed to board with fastening screws  $\text{Ø}3 \times 13$  on the inner door face

## Installation method for handle and guiding carriage with # 12 mm board + # 4 mm mirror




If the board or mirror is too loose on the handle profiles, screw the handles to the board using  $\text{Ø}3 \times 10$  screws.

Screw are available from Sevroll-System


## VICTORIA II C

## Installation method for angle section K2-Decor




## ALFA II C

## Installation method for angle section MINI 11x17 mm




## FAWORYT II C

## Installation method for handle and guiding carriage with # 18 mm board



- When fitting handle profiles, do not use assembly adhesive
- The handle should be fixed to board with fastening screws  $\text{Ø}3 \times 13$  on the inner door face

## Installation method for handle and guiding carriage with # 12 mm board + # 4 mm mirror





If the board or mirror is too loose on the handle profiles, screw the handles to the board using  $\text{Ø}3 \times 10$  screws.


Screw are available from Sevroll-System

## FAWORYT II C


## Installation method for angle section MINI 11x17 mm

**ATTENTION!**

Angle section must be fastened to board with minimum 3 screws  $\text{Ø}3 \times 25$ .


**ATTENTION!**

Angle section must be fastened to board with minimum 3 screws  $\text{Ø}3 \times 25$ .





## Dimensions of opening



Handle length = door height

## BETA C

anti-dust brushes  
(self-adhesive)  
6.7 mm x 13 mmtextile door stop  
(self-adhesive)  
4.8 mm x 4 mm

#16, #18

## FOCUS

anti-dust brushes  
(self-adhesive)  
6.7 mm x 13 mmtextile door stop  
(self-adhesive)  
4.8 mm x 4 mm

#16, #18

door height	- h	$h = H - 42 \text{ mm}$		$h = H - 42 \text{ mm}$	
door wing height with soft-close fitted		Mini SV25/40/60 SV-25/50	$h = H - 42 \text{ mm}$	Mini SV25/40/60 SV-25/50	$h = H - 42 \text{ mm}$
		Top SV60/80, Central SV25/40	$h = H - 44 \text{ mm}$	Top SV60/80, Central SV25/40	$h = H - 44 \text{ mm}$
board height	- hb	$hb = h - 2 \text{ mm}$		$hb = h - 2 \text{ mm}$	
door width	- w	$w = (W - 3 \text{ mm} + Z) : N$		$w = (W - 3 \text{ mm} + Z) : N$	
board width	- wb	$wb = w - 3 \text{ mm}$		$wb = w - 3 \text{ mm}$	
angle section length	- la	$la = w - 32,5 \text{ mm}$		$la = w - 58 \text{ mm}$	


number of doors	- N	2	3	4	5	2	3	4	5
total overlap	- Z	29 mm	58 mm	87 mm	116 mm	30 mm	60 mm	90 mm	120 mm

## visual design – 4 wings





$$w = (W - 3 + 87) : 4$$

$$w = (W - 3 + 90) : 4$$



$$w = (W : 2 + 26) : 2$$

$$w = (W : 2 + 27) : 2$$



## ATTENTION!


Handle profile should be 2 mm longer than board height.

## WARNING


SEVROLL does not bear any responsibility for deformation resulting from the application of improper quality of boards (improper storage, improper humidity)

## BETA C

Installation method for handle and guiding carriage with # 16 mm or # 18 mm board



Installation method for angle section MINI 11 x 17 mm



## FOCUS

Installation method for handle and guiding carriage with # 16 mm or # 18 mm board




Installation method for angle section MINI 11 x 17 mm



- When fitting handle profiles, do not use assembly adhesive






## COMPONENTS


<b>Handle</b> L: 2.70 m  <b>FACTOR II C</b> #16, #18 <b>FOCUS II C</b> #16, #18	<b>Top track Gemini-Decor</b> L: 1.70 m, 2.35 m, 3.00 m, 4.05 m, 6.00 m  76 mm	<b>Bottom track Gemini-Decor II</b> L: 1.70 m, 2.35 m, 3.00 m, 4.05 m, 6.00 m  53 mm
<b>Guiding carriage Focus</b> 	<b>Angle section</b> <b>MINI 11 mm x 17 mm</b> L: 1.70 m, 2.35 m, 3.00 m Focus II C <b>K2 Decor</b> L: 1.70 m, 2.35 m, 3.00 m Factor II C	<b>Bottom carriage WD18C HI-TEC</b> 

With **FACTOR II, FOCUS II** set you may use bottom track **Elegant II with covering strip** along with bottom carriage WD 18V HI-TEC. **Fitting measurements are not affected.**









Dimensions of opening





Handle length = door height

		FACTOR II C		FOCUS II C	
		anti-dust brushes (self-adhesive) 6.7 mm x 13 mm textile door stop (inserted) 4.8 mm x 4 mm  <b>#16, #18</b>		anti-dust brushes (self-adhesive) 6.7 mm x 13 mm textile door stop (inserted) 4.8 mm x 4 mm  <b>#16, #18</b>	
door height	- h	$h = H - 42 \text{ mm}$		$h = H - 42 \text{ mm}$	
door wing height with soft-close fitted		Mini SV25/40/60 SV-25/50	$h = H - 42 \text{ mm}$	Mini SV25/40/60 SV-25/50	$h = H - 42 \text{ mm}$
		Top SV60/80 Central SV25/40	$h = H - 44 \text{ mm}$	Top SV60/80 Central SV25/40	$h = H - 44 \text{ mm}$
board height	- hb	$hb = h - 2 \text{ mm}$		$hb = h - 2 \text{ mm}$	
door width	- w	$w = (W - 3 \text{ mm} + Z) : N$		$w = (W - 3 \text{ mm} + Z) : N$	
board width	- wb	$wb = w - 7 \text{ mm}$		$wb = w - 7 \text{ mm}$	
angle section length	- la	$la = w - 57.8 \text{ mm}$		$la = w - 55.4 \text{ mm}$	

number of doors	- N	2	3	4	5	2	3	4	5
total overlap	- Z	30 mm	60 mm	90 mm	120 mm	29 mm	58 mm	87 mm	116 mm

visual design – 4 wings					
		$w = (W - 3 + 90) : 4$		$w = (W - 3 + 87) : 4$	
		$w = (W : 2 + 27) : 2$		$w = (W : 2 + 26) : 2$	



**ATTENTION!**

Handle profile should be 2 mm longer than board height.




**WARNING**

SEVROLL does not bear any responsibility for deformation resulting from the application of improper quality of boards (improper storage, improper humidity)

Installation method for handle and guiding carriage with # 16 mm or # 18 mm board

**FACTOR II C**

Installation method for angle section K2-Decor


**FOCUS II C**

Installation method for angle section MINI 11 x 17 mm




- When fitting handle profiles, do not use assembly adhesive






## COMPONENTS

<b>Handle #18</b> L 2.70 m textile door stop (self-adhesive) 4.8 mm x 4 mm textile door stop (inserted) 4.8 mm x 4 mm anti-dust brushes (inserted) 6.7 mm x 13 mm <b>Secret Line</b> <b>Slim Line</b>		<b>Top track Gemini-Decor</b> L: 1.70 m, 2.35 m, 3.00 m, 4.05 m, 6.00 m 76 mm
<b>Bottom track Gemini-Decor II</b> L: 1.70 m, 2.35 m, 3.00 m, 4.05 m, 6.00 m 53 mm	<b>Angle section MINI</b> L: 1.70 m, 2.35 m, 3.00 m 11 mm x 17 mm	<b>Guiding carriage Focus</b>
		<b>Bottom carriage WD18C HI-TEC</b>



**door filling - # 18 board**



- When fitting handle profiles, do not use assembly adhesive

handle length = door height

		SLIM LINE	SECRET LINE
door height	- h	$h = H - 42 \text{ mm}$	$h = H - 42 \text{ mm}$
door wing height with soft-close fitted		Mini SV25/40/60 SV-25/50	Mini SV25/40/60 SV-25/50
		h = H - 42 mm	h = H - 42 mm
		Top SV60/80, Central SV25/40	Top SV60/80, Central SV25/40
		h = H - 44 mm	h = H - 44 mm
board height	- hb	$hb = h - 2 \text{ mm}$	$hb = h - 2 \text{ mm}$
door width	- w	$w = (W - 3 \text{ mm} + Z) : N$	$w = (W - 3 \text{ mm} + Z) : N$
board width	- wb	$wb = w - 6 \text{ mm}$	$wb = w - 3 \text{ mm}$
angle section length	- la	$la = w - 16 \text{ mm}$	$la = w - 7 \text{ mm}$

number of doors	- N	2	3	4	5	2	3	4	5
total overlap	- Z	25 mm	50 mm	75 mm	100 mm	25 mm	50 mm	75 mm	100 mm

visual design – 4 wings			
		$w = (W - 3 + 75) : 4$	$w = (W - 3 + 75) : 4$
		$w = (W : 2 + 22) : 2$	$w = (W : 2 + 22) : 2$


**ATTENTION!**

Handle profile should be 2 mm longer than board height.

**WARNING**

SEVROLL does not bear any responsibility for deformation resulting from the application of improper quality of boards (improper storage, improper humidity)







## COMPONENTS

<b>Handle Universal C</b> L: 2.70 m anti-dust brushes (self-adhesive) 6.7 mm x 9 mm textile door stop (inserted) 4.8 mm x 4 mm <b>#16, #18</b>	<b>Top track Gemini-Decor</b> L: 1.0 m, 2.35 m, 3.00 m, 4.05 m, 6.00 m 76 mm	<b>Bottom track Gemini-Decor II</b> L: 1.0 m, 2.35 m, 3.00 m, 4.05 m, 6.00 m 53 mm
<b>Angle section Mini</b> L: 1.0 m, 2.35 m, 3.00 m 11 mm x 17 mm	<b>Guiding carriage Focus</b>	<b>Bottom carriage WD18C HI-TEC</b>

With **UNIVERSAL** set  
you may use bottom track  
**Elegant II with covering  
strip** along with bottom  
carriage WD 18V HI-TEC.  
**Fitting measurements  
are not affected.**




Stopper **HI-TEC**





## Dimensions of opening

**door filling**

- # 18 mm
- # 12 board with # 4 mm mirror


Handle length = door height

door height	- h	$h = H - 42 \text{ mm}$
door wing height with soft-close fitted	Mini SV25/40/60 SV-25/50	$h = H - 42 \text{ mm}$
	Top SV60/80 Central SV25/40	$h = H - 44 \text{ mm}$
board height	- hb	$hb = h - 2 \text{ mm}$
door width	- w	$w = (W - 3 \text{ mm} + Z) : N$
board width	<b>#18</b> - wb	$wb = w - 7 \text{ mm}$
board width	<b>#12</b> - wb <sub>m</sub>	$wb_m = d - 7 \text{ mm}$
angle section length	- la	$la = w - 62.4 \text{ mm}$

number of doors	- N	2	3	4	5
total overlap	- Z	32 mm	64 mm	96 mm	128 mm

## visual design – 4 wings

	$w = (W - 3 + 96) : 4$
	$w = (W : 2 + 29) : 2$




## mirror dimension

mirror height	- hm = hb - 4 mm
mirror width	- wm = wb <sub>m</sub> - 4 mm

**ATTENTION:**


board to mirror contact area should be free from dirt and grase before applying double-sided tape

Broken line indicates recommended positioning of double-sided tape




- When fitting handle profiles, do not use assembly adhesive
- The handle should be fixed to board with fastening screws on the inner door face


## Installation method for handle and guiding carriage with # 18 mm board



## Installation method for handle and guiding carriage with # 12 mm board + # 4 mm mirror



## Installation method for angle section 11 mm x 17 mm

**ATTENTION!**

Angle section must be fastened to board with minimum 3 screws  $\varnothing 3 \times 25$

**ATTENTION!**


Handle profile should be 2 mm longer than board height.

**WARNING**

SEVROLL does not bear any responsibility for deformation resulting from the application of improper quality of boards (improper storage, improper humidity)

**ATTENTION!**

Remove protective film from aluminium elements (handles, tracks, connectors, etc.) prior to cutting them to the desired size. Film removal will reveal quality issues (eg. scratches).



## COMPONENTS

Handle	
L: 2.70 m 3.00 m	Arte GM
L: 2.70 m	Prosper GM
	Porto GM


Top track Gemini-Dekor	
L: 1.70 m, 2.35 m 3.00 m, 4.05 m 6.00 m	
76 mm	

Bottom track Gemini-Dekor II	
L: 1.70 m, 2.35 m 3.00 m, 4.05 m 6.00 m	
53 mm	

Guiding carriage	
GM18 asymmetrical	
or	
GM18 symmetrical	


Angle section	
MINI 11 mm x 17 mm	
L: 1.70 m, 2.35 m, 3.00 m	
K2 Dekor	
L: 1.70 m, 2.35 m, 3.00 m	

Bottom carriage WD18C HI-TEC	




Handle length = door height

## LINE PORTO GM

Guiding carriage  
GM18 symmetrical



## LINE PROSPER GM

Guiding carriage  
GM18 symmetrical


door height	- h	$h = H - 42 \text{ mm}$		$h = H - 42 \text{ mm}$	
door wing height with soft-close fitted		Mini SV25/40/60 SV-25/50	$h = H - 42 \text{ mm}$	Mini SV25/40/60 SV-25/50	$h = H - 42 \text{ mm}$
		Top SV60/80, Central SV25/40	$h = H - 44 \text{ mm}$	Top SV60/80, Central SV25/40	$h = H - 44 \text{ mm}$
board height	- hb	$hb = h - 2 \text{ mm}$		$hb = h - 2 \text{ mm}$	
door width	- w	$w = (W - 3 \text{ mm} + Z) : N$		$w = (W - 3 \text{ mm} + Z) : N$	
board width	- wb	$wb = w - 41 \text{ mm}$		$wb = w - 31 \text{ mm}$	
angle section length	- la	$la = w - 58 \text{ mm}$		$la = w - 48 \text{ mm}$	

number of doors	- N	2	3	4	5	2	3	4	5
total overlap	- Z	30 mm	60 mm	90 mm	120 mm	25 mm	50 mm	75 mm	100 mm

visual design – 4 wings		
	$w = (W - 3 + 90) : 4$	$w = (W - 3 + 75) : 4$
	$w = (W : 2 + 27) : 2$	$w = (W : 2 + 22) : 2$




- When fitting handle profiles, do not use assembly adhesive
- The handle should be fixed to board with fastening screws on the inner door face



**ATTENTION!**  
Handle profile should be 2 mm longer than board height.

**WARNING**  
SEVROLL does not bear any responsibility for deformation resulting from the application of improper quality of boards (improper storage, improper humidity)








Handle length = door height		
LINE ARTE GM		
<p><b>Handle Arte GM</b></p> <p>anti-dust brushes (inserted) 4.8 mm x 13 mm</p> <p>textile door stop (inserted) 14 mm x 4 mm</p>	<p><b>Guiding carriage GM18 asymmetrical</b></p> <p>L/R</p>	
door height - h	$h = H - 42 \text{ mm}$	
door wing height with soft-close fitted	Mini SV25/40/60 SV-25/50	$h = H - 42 \text{ mm}$
	Top SV60/80, Central SV25/40	$h = H - 44 \text{ mm}$
board height - hb	$hb = h - 2 \text{ mm}$	
door width - w	$w = (W - 3 \text{ mm} + Z) : N$	
board width - wb	$wb = w - 32 \text{ mm}$	
angle section length - la	$la = w - 48 \text{ mm}$	

number of doors - N	2	3	4	5
total overlap - Z	36 mm	72 mm	108 mm	144 mm

visual design – 4 wings	
	$w = (W - 3 + 108) : 4$
	$w = (W : 2 + 33) : 2$



- When fitting handle profiles, do not use assembly adhesive
- The handle should be fixed to board with fastening screws on the inner door face



## ATTENTION!

Handle profile should be 2 mm longer than board height.

## WARNING

SEVROLL does not bear any responsibility for deformation resulting from the application of improper quality of boards (improper storage, improper humidity)

